Pull-out hanger

Components



screw **Ø4x16** x4

1. Installation of the pull-out hanger



Mark out the positioning of the hanger

Fully extend the hanger from the guide (**1**), and then fasten with **ø4x16** screws (**2**)

Note: The set includes **Ø4x16** screws