



**1** **2** **3**

**1a** **1b**

**Fastening of top track**  
(countersink holes to prevent protrusion of screw head)

**Positioner for top carriage FIX**

**Door filling:**  
18 mm board

**Door filling:**  
12 mm board  
+ 4 mm mirror

**important dimension**

**Max. weight of 50 kg per door**

**ATTENTION**  
When installing the fixed mounting, it is important to situate axis L parallel to axis K (L || K)

**ATTENTION:**  
For fast and accurate routing of the bottom carriage pockets we recommend using stencil for bottom carriage WD18 HI-TEC index 20191

**Fastening of bottom track** (countersink holes to prevent protrusion of screw head)

**Option: bottom track Doubler II**

With **Comfort** set you may use bottom track **Doubler II** with **covering strip** along with bottom carriage WD18V HI-TEC. **Fitting measurements are not affected.**

**Fastening of bottom track**


**Stopper HI-TEC**

**COMPONENTS**

<p><b>Handle Comfort II</b></p> <p>L: 2.70 m</p> <p>textile door stop (inserted) 4.8 mm x 4 mm</p> <p>anti-dust brush (self-adhesive) 6.7 mm x 13 mm #16, #18</p>	<p><b>Top track Comfort-Decor</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p> <p>94 mm</p>	<p><b>Bottom track Comfort</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p> <p>62 mm</p>
<p><b>Guiding carriage Comfort</b></p>	<p><b>Angle section ZW</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m</p> <p>20 mm x 18 mm</p>	<p><b>Bottom carriage WD 18C HI-TEC</b></p>



Dimensions of opening




Handle length = door height

door height	- h	h = H - 42 mm	
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	h = H - 42 mm	
	Top SV60/80, Central SV25/40	h = H - 44 mm	
board height	- hb	hb = h - 2 mm	
door width	- w	w = (W - 3 mm + Z) : N	
board width #18	- wb	wb = w - 7 mm	
board width #12	- wb <sub>m</sub>	wb <sub>m</sub> = w - 7 mm	
angle section length	- la	this size is determined after door construction	

number of doors	- N	2	3	4	5
total overlap	- Z	35 mm	70 mm	105 mm	140 mm

visual design – 4 wings

	w = (W - 3 + 105) : 4
	w = (W : 2 + 32) : 2




mirror dimensions

mirror height	- hm = hb - 4 mm
mirror width	- wm = wb <sub>m</sub> - 34 mm


**ATTENTION:**  
board to mirror contact area should be free from dirt and grase before applying double-sided tape

Broken line indicates recommended positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face



Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror (handle Comfort # 16 mm)



Installation method for angle section 20 mm x 18 mm



**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws Ø 3 x 25.

**ATTENTION!**  
Handle profile should be 2 mm longer than board height.

**WARNING**  
SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)