




## COMPONENTS




With **Unicomfort** set you may use bottom track ***Doubler II*** ***with covering strip*** along with bottom carriage WD18V HI-TEC. **Fitting measurements are not affected.**



Option: bottom track Doubler II



Dimensions of opening




Handle length = door height

|   |                              |   |  |
|---|------------------------------|---|--|
| door height                             | - h                          | $h = H - 42 \text{ mm}$                         |  |
| door wing height with soft-close fitted | Mini SV25/40/60, SV-25/50    | $h = H - 42 \text{ mm}$                         |  |
|   | Top SV60/80, Central SV25/40 | $h = H - 44 \text{ mm}$                         |  |
| board height                            | - hb                         | $hb = h - 2 \text{ mm}$                         |  |
| door width                              | - w                          | $w = (W - 3 \text{ mm} + Z) : N$                |  |
| board width #18                         | - wb                         | $wb = w - 40 \text{ mm}$                        |  |
| board width #12                         | - wb <sub>m</sub>            | $wb_m = w - 7 \text{ mm}$                       |  |
| angle section length                    | - la                         | this size is determined after door construction |  |

|                     |       |       |        |        |
|---------------------|-------|-------|--------|--------|
| number of doors - N | 2     | 3     | 4      | 5      |
| total overlap - Z   | 35 mm | 70 mm | 105 mm | 140 mm |

visual design – 4 wings

|  |                         |
|--|-------------------------|
|  | $w = (W - 3 + 105) : 4$ |
|  | $w = (W : 2 + 32) : 2$  |




mirror dimensions

|               |                                |
|---------------|--------------------------------|
| mirror height | - hm = hb - 4 mm               |
| mirror width  | - wm = wb <sub>m</sub> - 36 mm |


**ATTENTION:**  
board to mirror contact area should be free from dirt and grase before applying double-sided tape

Broken line indicates recommended positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face


Installation method for handle and guiding carriage with # 18 mm board



Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror



Installation method for angle section ZW (20 mm x 18 mm)



### ATTENTION!

Angle section must be fastened to board with minimum 3 screws  $\varnothing 3 \times 25$ .

### ATTENTION!

Handle profile should be 2 mm longer than board height.

### WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)