
GEMINI 10

LINE


LEX




You must remember to purchase self-tapping screws to construct each door (4 screws per door). When using safety glass, you must also remember to purchase gaskets.



SEVROLL





door filling:


# 10 mm board


#4 mm mirror

		1			
door height	- h	h = F	h = H - 40 mm		
door wing height with soft-close fitted		ni SV40/60, /-25/50	h = H - 40 mm		
		o SV60/80, ntral SV-40	h = H - 44 mm		
board height	- hb	hb =	• h - 97 mm		
door width	- W	w = (W	w = (W - 3 mm + Z) : N		
board width	- wb	wb = w - 101 mm			
lower horizontal profile length upper horizontal profile length		L = U :	= w - 118 mm		
mirror height	- hm	hm = hb			
mirror width	- wm	wm = wb - 4 mm			

number of doors	- N	2	3	4	5	
total overlap	- Z	60 mm	120 mm	180 mm	240 mm	


visual design – 4 wings				
door set up	w = (W - 3 + 180) : 4			
door set up	w = (W : 2 + 57) : 2			







Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)

- with handle





construction clearance included in the calculation of the height of board



## **ATTENTION!**

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets U.

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired ATTENTION! size. Film removal will reveal quality issues (eg. scratches)